# Steri-Pak LF 121 Bowie-Dick Test Pack BD 121

#### Indications for Use

The Steri-Pak LF 121 Bowie-Dick Test Pack is designed for daily monitoring of pre-vacuum steam sterilizers operating at 121°C for 11 minutes with sub-atmospheric or trans-atmospheric cycles as defined in ISO 11140-4 to detect the presence of residual air.

# Color Change

The indicator will change from blue to black when exposed to a steam sterilization cycle with acceptable vacuum cycles.

#### Instructions for Use

The Bowie-Dick test is conducted each day in an empty sterilizer prior to processing any loads.

- 1. Run a warm up cycle to properly heat the sterilizer.
- 2. Place the test pack on the bottom of the sterilizer nearest to the drain. The test pack should read "THIS SIDE UP" when placed correctly.
- 3. Run the sterilizer for 11 minutes at 121°C.
- 4. Remove the test pack from the sterilizer and allow the pack to cool.
- 5. Pull easy open zip tab across box front to open.
- 6. Remove indicator from the pack. If the indicator sheet is still warm upon removal from the pack, do not place it on a cold surface. The indicator may return to original color if a cold surface is encountered prior to indicator equilibration. Dispose of or recycle remaining pack materials.

## Interpretation

- 1. If the sterilizer is functioning properly, the indicator will show a uniform black color change throughout the entire pattern.
- 2. When a significant amount of residual air is present, the indicator shows a blue area in the center.
- 3. On rare occasions, bubbling of the laminate may occur. If this happens, analyze the card for appropriate color change as instructed above.

## **Safety Precautions**

CAUTION: the test pack will be hot and should be opened carefully to avoid thermal injury.

#### Storage

- Store at normal room temperature 10° 38°C and 10-70% R.H.
- Store exposed indicator sheet away from light sources

# **Expiry Date**

The expiry date is printed on the product packaging. Do not use after expiration date listed on the packaging.

# **LOT Number**

A unique identification code, LOT, is printed on each indicator and packaging labels.

# **Interfering Substances or Conditions**

There are no known interfering substances or conditions that could affect the intended use of the indicator or adversely affect the indicator performance.

### **Release of Toxic Substances**

The indicator releases no known toxic substances in sufficient quantities to cause either a health hazard, or a hazard to the intended properties of the product being sterilized before, during or after the sterilization process.

## **Declaration of Conformity**

The Steri-Pak LF 121 Bowie-Dick Test Pack indicator conforms to all applicable portions of ISO 11140-1 Type 2 indicators for use in specific tests and ISO 11140-4.



DF-188 Rev. D